



USB Orientation



Receptacle

Orientation



Front

Rear



N






A



B



Plug



"N" Orientation

"A" Orientation

"B" Orientation

The Orientation Direction Shown is for Cable Assembly Only